

# WEBRelay<sup>TM</sup> 10

## Quick Start Guide




### Basic Setup Steps:

- (1) Connect unit to power and network only.
- (2) Set up a computer on the same network to configure WebRelay-10<sup>TM</sup>. To do this, set the IP address of the computer to 192.168.1.50 with a netmask of 255.255.255.0.
- (3) Configure WebRelay-10<sup>TM</sup> using web browser. Do this by pointing browser to <http://192.168.1.2/setup.html>. Password is webrelay (all lower case).
- (4) Set the permanent IP address in the configuration page. Restart WebRelay-10<sup>TM</sup> (remove power, re-apply power). After restarting the unit, set your computer back to it's original settings and access WebRelay-10<sup>TM</sup> at its new IP address.
- (5) Connect relay contacts.

### Factory Default Settings

IP Address: 192.168.1.2  
Subnet Mask: 255.255.255.0  
Control Web Address: <http://192.168.1.2>  
Setup Web Address: <http://192.168.1.2/setup.html>  
Username: *no username required*  
Control Password: *no password set*  
Setup Password: webrelay (all lower case)



Full Users Manual may be downloaded from  
<http://www.ControlByWeb.com>

For technical support, email questions to  
[support@ControlByWeb.com](mailto:support@ControlByWeb.com)



a division of...  
Xytronix Research & Design, Inc.  
North Logan, Utah, USA