

## Basic Setup Steps

---

1. Power the module and connect to network.
2. Set IP address on computer to be on the same network as the module. (Example: Set computer to 192.168.1.50)
3. To configure the module, open a web browser and enter:  
`http://192.168.1.2/setup.html`
4. Assign permanent IP address to module, then restart module.
5. Restore computer's IP address, if necessary, and access the module at its new IP address to finish setup.

## Factory Default Settings

---

**IP Address:** 192.168.1.2

**Subnet Mask:** 255.255.255.0

**Control Page Web Address:** `http://192.168.1.2`


**Control Password:** *(no password set)*

**Setup Page Web Address:** `http://192.168.1.2/setup.html`

**Setup Username:** admin

**Setup Password:** webrelay *(all lower case)*

# WebRelay | Pinout Diagram



Relay

- C:** Relay Contact Common
- NO:** Relay Contact Normally Open
- NC:** Relay Contact Normally Closed

Power

- V IN+:** Power Supply Input (9-28VDC)
- V IN-:** Power Supply Input (Ground)

Digital Input

- INPUT-:** Optically-Isolated Input (-)
- INPUT+:** Optically-Isolated Input (+)
- +5V OUT:** 5VDC Output